

Pilot devices - compact 22mm

Pushbuttons



Pushbuttons				Product Hierarchy 1300001	
Type	Contacts		Part No	Order Code	LVE Item
	N/O	N/C			
Flush momentary	1	-	CP1-10 ■-10	1SFA619100R101□	
	2	-	CP1-10 ■-20	1SFA619100R102□	
	-	1	CP1-10 ■-01	1SFA619100R104□	
	-	2	CP1-10 ■-02	1SFA619100R105□	
	1	1	CP1-10 ■-11	1SFA619100R107□	
Flush maintained	1	-	CP2-10 ■-10	1SFA619101R101□	
	2	-	CP2-10 ■-20	1SFA619101R102□	
	-	1	CP2-10 ■-01	1SFA619101R104□	
	-	2	CP2-10 ■-02	1SFA619101R105□	
	1	1	CP2-10 ■-11	1SFA619101R107□	
Extended momentary	1	-	CP3-10 ■-10	1SFA619102R101□	
	2	-	CP3-10 ■-20	1SFA619102R102□	
	-	1	CP3-10 ■-01	1SFA619102R104□	
	-	2	CP3-10 ■-02	1SFA619102R105□	
	1	1	CP3-10 ■-11	1SFA619102R107□	
Extended maintained	1	-	CP4-10 ■-10	1SFA619103R101□	
	2	-	CP4-10 ■-20	1SFA619103R102□	
	-	1	CP4-10 ■-01	1SFA619103R104□	
	-	2	CP4-10 ■-02	1SFA619103R105□	
	1	1	CP4-10 ■-11	1SFA619103R107□	

LVE Items
Please refer to page 44

Order example:
 Ex 1: Type CP1-10■-10, to order color red replace ■ with R: CP1-10 R-10
 Ex 2: Order code 1SFA619100R101□
 To order color red replace □ with 1: 1SFA619100R1011

Color codes								
	Red	Green	Yellow	Blue	White	Black	Grey	Clear
	●	●	●	●	○	●	●	○
Type ■	R	G	Y	L	W	B	U	C
Order Code □	1	2	3	4	5	6	7	8

Bezel - How to order
 Black - Standard
 Chrome metal - Replace '1' with '3' in Type and Order Codes

Bezel options	Type	Order code
Black plastic	CP(X)-10X-XX	1SFA619 X0X R10XX
Chrome metal	CP(X)-30X-XX	1SFA619 X0X R30XX

