

CONTACTUM

iCONIC



iCONIC

The iCONIC slimline range products have a much sharper profile - when installed the metal plate has a distinct outline which is ideal for the modern interior. Optional features include metal rockers.

- 4.5mm depth slim plate
- Square contemporary profile
- Available in 4 finishes
- 25 year guarantee



CONTACTUM
Make The Switch

iCONIC



10 AX Switches

1 Gang 10AX Intermediate Switch Black	C3710	BSB	PSB	PCB	BBB
1 Gang 10AX Intermediate Switch Black Metal Rocker	C3710	BSBM	PSBM	PCBM	BBBM
1 Gang 10AX Intermediate Switch White	C3710	BSW	PSW	PCW	BBW
1 Gang 10AX Intermediate Switch White Metal Rocker	C3710	BSWM	PSWM	PCWM	BBWM
1 Gang 2 Way 10AX Switch Black	C3712	BSB	PSB	PCB	BBB
1 Gang 2 Way 10AX Switch Black Metal Rocker	C3712	BSBM	PSBM	PCBM	BBBM
1 Gang 2 Way 10AX Switch White	C3712	BSW	PSW	PCW	BBW
1 Gang 2 Way 10AX Switch White Metal Rocker	C3712	BSWM	PSWM	PCWM	BBWM
3 Pole Fan Isolator 10AX Black	C3713	BSB	PSB	PCB	BBB
3 Pole Fan Isolator 10AX White	C3713	BSW	PSW	PCW	BBW
1 Gang 10AX DP Switch Black	C3718	BSB	PSB	PCB	BBB
1 Gang 10AX DP Switch Black Metal Rocker	C3718	BSBM	PSBM	PCBM	BBBM
1 Gang 10AX Double Pole Switch White	C3718	BSW	PSW	PCW	BBW
1 Gang 10AX DP Switch White Metal Rocker	C3718	BSWM	PSWM	PCWM	BBWM
2 Gang 2 Way 10AX Switch Black	C3722	BSB	PSB	PCB	BBB
2 Gang 2 Way 10AX Switch Black Metal Rocker	C3722	BSBM	PSBM	PCBM	BBBM
2 Gang 2 Way 10AX Switch White	C3722	BSW	PSW	PCW	BBW
2 Gang 2 Way 10AX Switch White Metal Rocker	C3722	BSWM	PSWM	PCWM	BBWM
2 Gang 10AX Intermediate Switch Black	C3723	BSB	PSB	PCB	BBB
2 Gang 10AX Intermediate Switch White	C3723	BSW	PSW	PCW	BBW
3 Gang 2 Way 10AX Black	C3732	BSB	PSB	PCB	BBB
3 Gang 2 Way 10AX Black Metal Rocker	C3732	BSBM	PSBM	PCBM	BBBM
3 Gang 2 Way 10AX White	C3732	BSW	PSW	PCW	BBW
3 Gang 2 Way 10AX White Metal Rocker	C3732	BSWM	PSWM	PCWM	BBWM
1 Gang 10AX Bell Push Switch Black	C3736	BSB	PSB	PCB	BBB
1 Gang 10AX Bell Push Switch Black Metal Rocker	C3736	BSBM	PSBM	PCBM	BBBM
1 Gang 10AX Bell Push Switch White	C3736	BSW	PSW	PCW	BBW
1 Gang 10AX Bell Push Switch White Metal Rocker	C3736	BSWM	PSWM	PCWM	BBWM
4 Gang 2 Way 10AX Switch Black	C3742	BSB	PSB	PCB	BBB
4 Gang 2 Way 10AX Switch Black Metal Rocker	C3742	BSBM	PSBM	PCBM	BBBM
4 Gang 2 Way 10AX Switch White	C3742	BSW	PSW	PCW	BBW
4 Gang 2 Way 10AX Switch White Metal Rocker	C3742	BSWM	PSWM	PCWM	BBWM
6 Gang 2 Way 10AX Switch Black	C3762	BSB	PSB	PCB	BBB
6 Gang 2 Way 10AX Switch Black Metal Rocker	C3762	BSBM	PSBM	PCBM	BBBM
6 Gang 2 Way 10AX Switch White	C3762	BSW	PSW	PCW	BBW
6 Gang 2 Way 10AX Switch White Metal Rocker	C3762	BSWM	PSWM	PCWM	BBWM



2 Amp -15 Amp Sockets

1 Gang 2A 3 Pin Unswitched Socket Black	C3315	BSB	PSB	PCB	BBB
1 Gang 2A 3 Pin Unswitched Socket White	C3315	BSW	PSW	PCW	BBW
1 Gang 15A Switched Socket Single Pole Black	C3336	BSB	PSB	PCB	BBB
1 Gang 15A Switched Socket Single Pole White	C3336	BSW	PSW	PCW	BBW



1 Gang 13 Amp Sockets

Unswitched Black	C3345	BSB	PSB	PCB	BBB
Unswitched White	C3345	BSW	PSW	PCW	BBW
Switched DP Black	C3346	BSB	PSB	PCB	BBB
Switched DP Black Metal Rocker	C3346	BSBM	PSBM	PCBM	BBBM
Switched DP White	C3346	BSW	PSW	PCW	BBW
Switched DP White Metal Rocker	C3346	BSWM	PSWM	PCWM	BBWM
Switched DP Neon Black	C3347	BSB	PSB	PCB	BBB
Switched DP Neon Black Metal Rocker	C3347	BSBM	PSBM	PCBM	BBBM
Switched DP Neon White	C3347	BSW	PSW	PCW	BBW
Switched DP Neon White Metal Rocker	C3347	BSWM	PSWM	PCWM	BBWM


DP - Double Pole



2 Gang 13 Amp Sockets

Unswitched Black	C3355	BSB	PSB	PCB	BBB
Unswitched White	C3355	BSW	PSW	PCW	BBW
Switched DP Black	C3356	BSB	PSB	PCB	BBB
Switched DP Black Metal Rocker	C3356	BSBM	PSBM	PCBM	BBBM
Switched DP White	C3356	BSW	PSW	PCW	BBW
Switched DP White Metal Rocker	C3356	BSWM	PSWM	PCWM	BBWM
Switched DP Neon Black	C3357	BSB	PSB	PCB	BBB
Switched DP Neon Black Metal Rocker	C3357	BSBM	PSBM	PCBM	BBBM
Switched DP Neon White	C3357	BSW	PSW	PCW	BBW
Switched DP Neon White Metal Rocker	C3357	BSWM	PSWM	PCWM	BBWM

DP - Double Pole



45 Amp Double Pole Switches

45A DP Cooker Control Black	C3456	BSB	PSB	PCB	BBB
45A DP Cooker Control White	C3456	BSW	PSW	PCW	BBW
45A DP Cooker Control Neon Black	C3457	BSB	PSB	PCB	BBB
45A DP Cooker Control Neon White	C3457	BSW	PSW	PCW	BBW

DP - Double Pole



45 Amp Switches

1 Gang DP (2 Gang Vertical Plate) Black	C3746	BSB	PSB	PCB	BBB
1 Gang DP (2 Gang Vertical Plate) White	C3746	BSW	PSW	PCW	BBW
1 Gang DP (2 Gang Vertical Plate) Neon Black	C3747	BSB	PSB	PCB	BBB
1 Gang DP (2 Gang Vertical Plate) Neon White	C3747	BSW	PSW	PCW	BBW
1 Gang DP (1 Gang Plate) Black	C3756	BSB	PSB	PCB	BBB
1 Gang DP (1 Gang Plate) White	C3756	BSW	PSW	PCW	BBW
1 Gang DP (1 Gang Plate) Neon Black	C3757	BSB	PSB	PCB	BBB
1 Gang DP (1 Gang Plate) Neon White	C3757	BSW	PSW	PCW	BBW

DP - Double Pole



13 Amp Connection Units

Unswitched Neon Black	C3362	BSB	PSB	PCB	BBB
Unswitched Neon White	C3362	BSW	PSW	PCW	BBW
Unswitched With Flex Outlet Neon Black	C3363	BSB	PSB	PCB	BBB
Unswitched With Flex Outlet Neon White	C3363	BSW	PSW	PCW	BBW
Unswitched Black	C3364	BSB	PSB	PCB	BBB
Unswitched White	C3364	BSW	PSW	PCW	BBW
Unswitched With Flex Outlet Black	C3365	BSB	PSB	PCB	BBB
Unswitched With Flex Outlet White	C3365	BSW	PSW	PCW	BBW
Key Switch DP Black	C3366/5	BSB	PSB	PCB	BBB
Key Switch DP White	C3366/5	BSW	PSW	PCW	BBW
Switched DP Black	C3366	BSB	PSB	PCB	BBB
Switched DP Black Metal Rocker	C3366	BSBM	PSBM	PCBM	BBBM
Switched DP White	C3366	BSW	PSW	PCW	BBW
Switched DP White Metal Rocker	C3366	BSWM	PSWM	PCWM	BBWM
Connection Unit Key Switch DP Neon Black	C3367/5	BSB	PSB	PCB	BBB
Connection Unit Key Switch DP Neon White	C3367/5	BSW	PSW	PCW	BBW
Switched DP Neon Black	C3367	BSB	PSB	PCB	BBB
Switched DP Neon Black Metal Rocker	C3367	BSBM	PSBM	PCBM	BBBM
Switched DP Neon White	C3367	BSW	PSW	PCW	BBW
Switched DP Neon White Metal Rocker	C3367	BSWM	PSWM	PCWM	BBWM
Connection Unit Key Switch DP Flex Black	C3368/5	BSB	PSB	PCB	BBB
Connection Unit Key Switch DP Flex White	C3368/5	BSW	PSW	PCW	BBW
Switched DP With Flex Outlet Black	C3368	BSB	PSB	PCB	BBB
Switched DP Flex Outlet Black Metal Rocker	C3368	BSBM	PSBM	PCBM	BBBM
Switched DP Flex Outlet White	C3368	BSW	PSW	PCW	BBW
Switched DP Flex Outlet White Metal Rocker	C3368	BSWM	PSWM	PCWM	BBWM
Connection Unit Key Switch DP Flex Outlet Neon Black	C3369/5	BSB	PSB	PCB	BBB
Connection Unit Key Switch DP Flex Outlet Neon White	C3369/5	BSW	PSW	PCW	BBW
Switched DP Flex Outlet Neon Black	C3369	BSB	PSB	PCB	BBB
Switched DP Flex Outlet Neon Black Metal Rocker	C3369	BSBM	PSBM	PCBM	BBBM
Switched DP Flex Outlet Neon White	C3369	BSW	PSW	PCW	BBW
Switched DP Flex Outlet Neon White Metal Rocker	C3369	BSWM	PSWM	PCWM	BBWM

DP - Double Pole





Blank Plates

Single Blank Plate	C3017	BS	PS	PC	BB
Double Blank Plate	C3027	BS	PS	PC	BB

Co Axial Satellite, Data & Telephone Outlets

Single Data Plate 1 Module	C3107	BS	PS	PC	BB
Single Data Plate 2 Module	C3117	BS	PS	PC	BB
Double Data Plate 4 Module	C3127	BS	PS	PC	BB
Flex Outlet Black	C3137	BSB	PSB	PCB	BBB
Flex Outlet White	C3137	BSW	PSW	PCW	BBW
1 Gang Non Iso Coaxial Socket Black	C3147	BSB	PSB	PCB	BBB
1 Gang Non Iso Coaxial Socket White	C3147	BSW	PSW	PCW	BBW
2 Gang Non Iso Coaxial (2 Downleads) Black	C3148	BSB	PSB	PCB	BBB
2 Gang Non Iso Coaxial (2 Downleads) White	C3148	BSW	PSW	PCW	BBW
2 Gang Coaxial & Satellite Socket Black	C3150	BSB	PSB	PCB	BBB
2 Gang Coaxial & Satellite Socket White	C3150	BSW	PSW	PCW	BBW
1 Gang Satellite Socket Black	C3151	BSB	PSB	PCB	BBB
1 Gang Satellite Socket White	C3151	BSW	PSW	PCW	BBW
2 Gang Satellite Socket Black	C3152	BSB	PSB	PCB	BBB
2 Gang Satellite Socket White	C3152	BSW	PSW	PCW	BBW
2 Gang Coaxial Satellite Diplexer (1 Downlead) Black	C3153	BSB	PSB	PCB	BBB
2 Gang Coaxial Satellite Diplexer (1 Downlead) White	C3153	BSW	PSW	PCW	BBW
1 Gang Iso Coaxial Socket Black	C3157	BSB	PSB	PCB	BBB
1 Gang Iso Coaxial Socket White	C3157	BSW	PSW	PCW	BBW
2 Gang Iso Coaxial (1 Downlead) Black	C3158	BSB	PSB	PCB	BBB
2 Gang Iso Coaxial (1 Downlead) White	C3158	BSW	PSW	PCW	BBW
TV/FM/DAB Triplexer Black	C3160	BSB	PSB	PCB	BBB
TV/FM/DAB Triplexer White	C3160	BSW	PSW	PCW	BBW
Telephone Master Socket Black	C3169	BSB	PSB	PCB	BBB
Telephone Master Socket White	C3169	BSW	PSW	PCW	BBW
Telephone Secondary Socket Black	C3170	BSB	PSB	PCB	BBB
Telephone Secondary Socket White	C3170	BSW	PSW	PCW	BBW
1 Gang Data Comms RJ45 Cat 5*	C3180	BSW	PSW	PCW	BBW
2 Gang Data Comms RJ45 Cat 5*	C3181	BSW	PSW	PCW	BBW
3 Gang Data Comms RJ45 Cat 5*	C3182	BSW	PSW	PCW	BBW
4 Gang Data Comms RJ45 Cat 5*	C3183	BSW	PSW	PCW	BBW

* Only available in white. Cat 6 modules and black modules are available to order.

Shaver Sockets

230 - 115 Volt Shaver Socket Black	C3300	BSB	PSB	PCB	BBB
230 - 115 Volt Shaver Socket White	C3300	BSW	PSW	PCW	BBW



Dimmer Switches

1 Gang 1 Way Dimmer 400 Watt	C3614/1	BS	PS	PC	BB
1 Gang 2 Way Dimmer 400 Watt	C3614/2	BS	PS	PC	BB
2 Gang 2 Way Dimmer 400 Watt	C3624/2	BS	PS	PC	BB
3 Gang 2 Way Dimmer 400 Watt	C3634/2	BS	PS	PC	BB
4 Gang 2 Way Dimmer 250 Watt	C3642/2	BS	PS	PC	BB
4 Gang 2 Way Dimmer 400 Watt	C3644/2	BS	PS	PC	BB



20 Amp Switches

1 Gang DP Switch Black	C3796	BSB	PSB	PCB	BBB
1 Gang DP Switch Black Metal Rocker	C3796	BSBM	PSBM	PCBM	BBBM
1 Gang DP Switch White	C3796	BSW	PSW	PCW	BBW
1 Gang DP Switch White Metal Rocker	C3796	BSWM	PSWM	PCWM	BBWM
1 Gang DP Switch Neon Black	C3797	BSB	PSB	PCB	BBB
1 Gang DP Switch Neon Black Metal Rocker	C3797	BSBM	PSBM	PCBM	BBBM
1 Gang DP Switch Neon White	C3797	BSW	PSW	PCW	BBW
1 Gang DP Switch Neon White Metal Rocker	C3797	BSWM	PSWM	PCWM	BBWM
1 Gang DP Switch Flex Outlet Black	C3798	BSB	PSB	PCB	BBB
1 Gang DP Switch With Flex Outlet Black Metal Rocker	C3798	BSBM	PSBM	PCBM	BBBM
1 Gang DP Switch Flex Outlet White	C3798	BSW	PSW	PCW	BBW
1 Gang DP Switch Flex Outlet White Metal Rocker	C3798	BSWM	PSWM	PCWM	BBWM
1 Gang DP Switch Flex Outlet Neon Black	C3799	BSB	PSB	PCB	BBB
1 Gang DP Switch Flex Outlet Neon Black Metal Rocker	C3799	BSBM	PSBM	PCBM	BBBM
1 Gang DP Switch Flex Outlet Neon White	C3799	BSW	PSW	PCW	BBW
1 Gang DP Switch Flex Outlet Neon White Metal Rocker	C3799	BSWM	PSWM	PCWM	BBWM

DP - Double Pole



RCD Sockets

2 Gang 13A Latching Socket DP Black	C4900	BSB	PSB	PCB	BBB
2 Gang 13A Latching Socket DP White	C4900	BSW	PSW	PCW	BBW
2 Gang 13A Non Latching Socket DP Black	C4901	BSB	PSB	PCB	BBB
2 Gang 13A Non Latching Socket DP White	C4901	BSW	PSW	PCW	BBW

CONTACTUM Make The Switch

Victoria Works, Edgware Road, Cricklewood, London NW2 6LF

T: 020 8208 7419 F: 020 8208 3340 E: sales@contactum.co.uk www.contactum.co.uk