WAGOBOX

Part Number Changes

Please note we have updated the following part numbers within the WAGOBOX range.

Going forward please order via the new part number.



Old Part No.	New Part No.	Description
60413514	**207-3301**	WAGOBOX 221-4 Single for 221 & 2773 series
60413516	**OBS* use singles**	WAGOBOX 221-4 pack 10
51008291	**207-3302**	WAGOBOX for 222 & 773 series
51008319	**OBS* use singles**	WAGOBOX pack 10 for 222 & 773 series
51303208	**207-3303**	WAGOBOX Light Single
51257303	**OBS* use singles**	WAGOBOX Light pack 10
51302077	**207-9310**	WAGOBOX Light 260 module (L+E+N)
51302078	**207-9311**	WAGOBOX Light 260 module (L1+E+L2+N)
51302076	**207-9308**	WAGOBOX Light thumb tool
60342671	**207-9314**	WAGOBOX Light 294 module (N+E+L)
60339091	**207-3304**	WAGOBOX XL
60358440	**207-3305**	WAGOBOX XLA
51009130	**207-9309**	WAGOBOX fixing button
51312606	**207-3307**	WAGOBOX Capsule Grey
51312607	**207-3308**	WAGOBOX Capsule Black
51312608	**207-3306**	WAGOBOX Capsule Clear
51312602	**207-9304**	WAGOBOX Capsule Lid plate
51312603	**207-9305**	WAGOBOX Capsule Side plate
51312590	**207-9302**	WAGOBOX Capsule Bracket Grey
51312594	**207-9303**	WAGOBOX Capsule Bracket Black
60413638	**207-9306**	WAGOBOX Capsule Post Bracket Grey
60413530	**207-9307**	WAGOBOX Capsule Post Bracket Black
60362958	**207-3309**	L32 Wiring Centre
60348650	**207-9313**	221 Series insert adapter for 221 series

*Obsolete