


**MAGZC-816**

4 Zone Expander Card


**MAGSC-816**

4 Zone Sounder Expander Card

**MAG-FMK**

Flush Mount Kit for MAG816


**MAGBAR816**

Spare Barrel &amp; Key


**MAG816**

8 Zone Fire Panel Expandable to 16 Zones



- Up to 16 programmable zones
- Up to 16 sounder circuits
- Active end of line monitoring and head removal
- Up to 32 fire detectors per zone
- Unlimited number of call points per zone
- Integral sound alarm button
- Repeater facility and 'Class change' facility
- Enable/disable security key
- One man walk test facility
- Volt free fire/fault change over relay
- Individual sounder circuit fault ID
- Individual zone/sounder isolate
- Alarm delay options
- CE certified to EN54 P2/4
- Requires 1 x 12V batteries
- ABS casing

**Inputs**

Max. Detectors per Zone	32
Thresholds for Zone Conditions	0 - 2 mA (Fault condition) 2 - 10 mA (Normal condition) 10 - 110 mA (Fire condition) 110mA - + Short (Fault condition)

**Power**

Mains Fail Consumption	130mA (1 zone expander) 260mA (4 zone expanders)
Mains Supply	230 VAC ± 10%
Standby Supply	1 x 18Ah 12V S.L.A. Batteries
Power Availability	0.7 amps

**Outputs**

On Board Sounder Circuits (4)	300mA @ 24V fuse resettable (PTC)
Sounder Expander Cards (4)	150mA @ 24V fuse resettable (PTC)
Fault/Fire Relay	Volt free 500mA @ 24V (max load)
Auxiliary Output	24VDC (300mA fused)

**Environment**

Working Temperature	0 to 40°C
Storage Temperature	-20 to 60°C
Humidity	0 to 93%
Dimensions (mm)	456 x 350 x 125mm
Weight	4.2 KG

**FIRE ZONE / SOUNDER OUTPUT MATRIX**

Number of zone cards fitted	2	3	4	2	3	1	2	1
Number of sounder cards fitted	0	0	0	1	1	2	2	3
Number of zones	8	12	16	8	12	4	8	4
Number of sounder outputs	4	4	4	8	8	12	12	16

NB The MAG816 features 4 sounder circuits. Space is provided for up to 4 extra expansion cards of any combination. Sounder cards carry 4 sounder circuits, Zone cards carry 4 fire zones. The MAG816 is supplied as standard with 8 fire zones and 4 sounder circuits.