



1.1

Product overview

PREMERA wiring accessories

Wall mounted range (contd)

Description	PREMERA range	COPA c/w cover	COPA interior	COPA black interior	COPA decorative plates ¹⁾	COPA metal plates ²⁾	COPA fix stainless steel	COPA fix highly polished	XTRA surface metal
13A connection units – unswitched with optional cable outlets									
13A connection unit	P220	C220WH	C220	C220B	CP220 ¹⁾	CM220 ²⁾	B220SS	–	X220MG
13A connection unit + red fuse drawer	P220RR	–	–	–	–	–	–	–	X220RRMG
13A connection unit fitted with 3A fuse	P224	–	–	–	–	–	–	–	–
13A connection units – unswitched + neon with optional cable outlets									
13A connection unit	P220N	C220NWH	C220N	C220NB	CP220N ¹⁾	CM220N ²⁾	B220NSS	–	X220NMG
13A connection unit fitted with 3A fuse	P223N	–	–	–	–	–	–	–	–
20A double pole switches with optional cable outlet									
20A switch	P401	C401WH	C401	C401B	CP401 ¹⁾	CM401 ²⁾	B401SS	–	X401MG
20A switch marked 'water heater'	P403	C403WH	–	–	–	CM403 ²⁾	–	–	–
20A double pole switches + neon with optional cable outlets									
20A switch	P401N	C401NWH	C401N	C401NB	CP401N ¹⁾	CM401N ²⁾	B401NSS	–	X401NMG
20A switch marked 'water heater'	P403N	C403NWH	–	–	CP403N ¹⁾	CM403N ²⁾	B403NSS	–	–
20A switch marked 'air conditioner'	P404N	–	–	–	–	–	B404NSS	–	–
45A double pole switches – cooker control units									
45A DP cooker control unit	P425	C425WH	C425	C425B	CP425 ¹⁾	CM425 ²⁾	–	–	–
45A DP cooker control unit + neon	P425N	C425NWH	C425N	C425NB	CP425N ¹⁾	CM425N ²⁾	B425NSS	–	–
50A double pole switches – 2 gang plate size									
50A DP switch	P421	–	–	–	–	–	–	–	X421MG
50A DP switch + neon	P421N	C421NWH	C421N	C421NB	CP421N ¹⁾	CM421N ²⁾	B421NSS	–	X421NMG
50A DP switch marked 'cooker'	P423	–	–	–	–	–	–	–	–
50A DP switch + neon marked 'cooker'	P423N	C423NWH	–	–	CP423N ¹⁾	CM423N ²⁾	–	–	–
50A DP switch + neon marked 'air conditioner'	P424N	C424NWH	–	–	CP424N ¹⁾	CM424N ²⁾	–	–	–
50A double pole switches – 1 gang plate size									
50A DP switch + neon	P422N	C422NWH	C422N	C422NB	CP422N ¹⁾	CM422N ²⁾	B422NSS	–	–
50A DP switch + neon – grey cover	P422NGY	–	C422N	–	CP422NGY	–	–	–	–
50A DP switch + neon marked 'cooker'	P426N	C426NWH	–	–	–	–	B426NSS	–	–
50A DP switch + neon marked 'air conditioner'	P427N	–	–	–	–	–	–	–	–
Cable/cooker outlet/cable outlet adaptor plate									
20A flex outlet plate	P210	–	–	–	–	–	–	–	–
Cable outlet adaptor plate for 20A switch/3A fused connection unit	P212	C212	–	–	–	–	–	–	–
45A DP cable outlet with terminal block	P345	–	–	–	–	–	–	–	–
Phone outlets									
1G telephone outlet master	P360	C360WH	C360	C360B	CP360 ¹⁾	CM360 ²⁾	B360SS	–	X360MG
1G telephone outlet secondary	P361	C361WH	C361	C361B	CP360 ¹⁾	CM360 ²⁾	B361SS	–	X361MG
1G american telephone outlet RJ11	P362	C362WH	C362	C362B	CP360 ¹⁾	CM360 ²⁾	–	–	–
Data outlets									
1G RJ45 CAT 6 outlet interior	–	C363WH	C363	C363B	CP360 ¹⁾	CM360 ²⁾	–	–	–
Communication outlets									
1G TV co-axial	P351	C351WH	C351	C351B	CP351 ¹⁾	CM351 ²⁾	B351SS	–	–
1G TV co-axial dual clamp	P351D	–	–	–	–	–	–	–	–
2G TV co-axial outlet	P352	C352WH	C352	C352B	CP352 ¹⁾	CM352 ²⁾	–	–	–
1G TV/FM isolated co-axial	P353	C353WH	C353	C353B	CP351 ¹⁾	CM351 ²⁾	–	–	–
2G TV/FM diplexer co-axial	P354	C354WH	C354	C354B	CP352 ¹⁾	CM352 ²⁾	B354SS	–	–
1G satellite	P355	C355WH	C355	C355B	CP351 ¹⁾	CM351 ²⁾	B355SS	–	–
2G TV/satellite	P356	C356WH	C356	C356B	CP352 ¹⁾	CM352 ²⁾	B356SS	–	–
2G TV/radio	P357	–	–	–	–	–	–	–	–
1G TV/radio/satellite return	–	C359WH	C359	C359B	CP359 ¹⁾	CM359 ²⁾	–	–	–
Blank plates									
1G blank plate	P391	C391WH	C391	C391	CP391 ¹⁾	CM391 ²⁾	B391SS	–	X391MG
2G blank plate	P392	C392WH	C392	C392	CP392 ¹⁾	CM392 ²⁾	B392SS	–	X392MG