


## ▶ DOWNLOAD THE APP


OPTION 1: Scan QR code:



OPTION 2: Search for the “ATC CALA” App.

## ▶ REGISTER IN THE APP

**STEP 1:** If you are not already registered, select “CREATE NEW ACCOUNT” and enter the requested data. Once all the information is complete, press “REGISTER”.



**STEP 2:** When the account is created, Login with your new account details.

**STEP 3:** Activation form.

Check your email and enter your activation code to complete the registration process.


ACTIVATION FORM

Activation code RESEND CODE


COMPLETE REGISTRATION

## ▶ LINK TO WIFI NETWORK


Do you want to configure WiFi for the Radiator?



### 1 CONNECTION BETWEEN RADIATOR AND MOBILE DEVICE




#### ▶ STEP 1: Activate the Radiator's connection.



**NOTE:** During WiFi linking, do not manipulate the interface screen.

► **STEP 2:** Connect the mobile device to the network shown on the radiator.

**OPTION 1:** On the menu “WIFI SETTINGS” of your mobile device, select the name “ATC\_01” and enter the password “00012108” of the wifi network displayed by the radiator.




**OPTION 2:** Using the camera of your mobile device, scan the QR code displayed on the radiator screen. \*

\* Depending on the capability of your mobile device.


\*\* If a pop-up message appears on your mobile device, confirm that it is a wifi network without internet access.

2

## CONNECTION BETWEEN RADIATOR AND LOCAL WIFI NETWORK




► **STEP 3:** In the App choose the WiFi network that the radiator will connect to. \*



\* Note that the iLifestyle will only work on 2.4 GHz wifi networks.

Enter the password for the selected WiFi network.

### 3 VERIFICATION OF THE CONNECTION



The radiator has been successfully linked.

Connection process completed. The radiator is ready to use with the App.

### ▶ CONTROL PANEL

MODE key opens and closes the menus.



Touch OK to accept selection.



MANUAL Mode.



Touch ARROW keys to navigate through the different menu options.



Use STANDBY key to switch the radiator on and off.

### ▶ FUNCTION MODES



For further information, please check the instructions manual on the ATC Website.



ATC Electrical and Mechanical  
 ATC House,  
 Broomhill Drive,  
 D24 EF99, Tallaght, IRELAND  
 IE Tel.: +353 1 467 8301 - UK Tel.: +44 0203 564 9164  
 Email: sales@atc.ie, sales@atcelec.co.uk  
 www.atc.ie www.atcelec.co.uk