





TANGO (1175005)



TANGO (1175004)




TANGO (1175002)



TANGO

	LAMP	WATT	INPUT	K	CRI	Lm	CLASS			
BSS 1175002 (0826)	PSS 1175005 (0833)	Integral LED	1W	350mA CC▼	3000	80	23	◊	✓	✓
BSS 1175007 (7523)	PSS 1175010 (7526)	Integral LED	2.6W	350mA CC▼	2700	80	29	◊	✓	-
MW 1175001 (0825)	TB 1175004 (0832)	Integral LED	1W	350mA CC▼	3000	80	23	◊	✓	✓
MW 1175006 (7522)	TB 1175009 (7525)	Integral LED	2.6W	350mA CC▼	2700	80	29	◊	✓	-



TANGO

▼ LAMP/INPUT SOURCE EXCLUDED, SEE PAGE 632. / La lampe / source d'entrée exclu, voir page 632. / La lampadina / input esclusi a pagina 634 / Das Leuchtmittel ist ausgeschlossen. Sie auf Seite 632.