

## SAFETY WARNING

Proper safety measures should be taken when working with voltages exceeding 30V AC rms, 42V AC peak or 60V DC. Your socket tester is not intended to replace good electrical practices. This unit must only be used under the conditions and for the purposes for which it has been constructed. Pay attention to these safety instructions, the technical specification and the use of the unit in dry surroundings.

#### PRE-TEST CHECK

Visually inspect the tester for any signs of physical damage, e.g. cracks, splits, loose pins or damaged indicators, etc. In the unlikely event of the socket tester sustaining physical damage, it should not be used. For good electrical practice it is recommended that you verify the function of the tester on a known correctly-wired live socket before & after use.

## **OPERATING INSTRUCTIONS**

Simply plug the Check Plug Socket Tester into a live 13A socket and switch the socket on. Three indicator LED's across the front of the unit provide a clear indication of a correctly wired socket. Fault indications are quickly identified using the key on the face label. Additional information can be found in the table opposite, showing 32 wiring conditions, of which 28 are faults that require investigation. In the event that a fault is indicated, investigation should only be carried out by a suitably qualified electrician.

### STORAGE AND MAINTENANCE

The socket tester should be kept in dry conditions and should be protected from moisture, condensation, physical damage and direct sources of heat. Ensure the unit is dry before use.

Cleaning: After removal from any socket, the unit may be cleaned using a soft, dry cloth. Solvents, liquids, detergents, surfactants and waxes should not be used.

There are no user serviceable parts inside.

#### WARRANTY

This item is warranted against defects in materials and manufacture for 24 months from the date of purchase. Return to Martindale Electric if faulty.

CE Equipment complies with relevant EU Directives

Caution - risk of danger & refer to instructions

Equipment protected by double or reinforced insulation (Class II)

- CAT II is applicable to test and measuring equipment connected directly to utilization points (socket outlets and similar points) of the low-voltage MAINS installation.
- ✓ Alternating Current (ac)

	E	L					
Socket Wires			CP LED's				
	Е	L	ок				
	Ν	L	Note 1				
	E	L	Note 1				
	Ν	L	Note 1				
	E	Ν	LN Reverse			1.1	Note 2
	Е	E	LN Reverse			1.1	Note 2
	Ν	Ε	LN Reverse			1.1	Note 2
	Ν	Ν	LN Reverse			1.1	Note 2
	L	L	LN Reverse				Note 2
	L	L	LN Reverse			1.1	Note 2
	OPEN	L	No Earth				Note 2
	OPEN	L	No Earth				Note 2
	OPEN	E	No Earth				Note 2
	OPEN	Ν	No Earth				Note 2
ĪN	E	L	N Fault				Note 2
ΕN	Ν	L	N Fault				Note 2
IN	L	E	N Fault				Note 2
IN	L	Ν	N Fault				Note 2
	L	E	LE Reverse			•	Note 2
	L	E	LE Reverse				Note 2
	L	Ν	LE Reverse				Note 2
	L	Ν	LE Reverse				Note 2
	E	L	LE Reverse				Note 2
	Ν	L	LE Reverse			•	Note 2
N	OPEN	L	EN Fault				Note 3
N	L	OPEN	LEN Fault				Note 3
	OPEN	OPEN	LEN Fault				Note 3
IN	L	L	LEN Fault				Note 3
	OPEN	L	LEN Fault				Note 3
	L	OPEN	LEN Fault				Note 3
IN	OPEN	OPEN	LEN Fault				Note 3
	L	L	L Fault				Note 3

With reference to table: Note 1 EN reversal not detectable.

OPE

OPE

OPE

OPE

OPE

OPE

OPE

OPE

Ν

Note 2 Investigation required by qualified electrician.

Note 3 Caution! Investigate with care. Socket wire(s) may be live, but LED's will not light. Investigation required by qualified electrician.

NOTE: This unit, in common with other simple socket testers, cannot detect Earth/Neutral reversal.

# TECHNICAL SPECIFICATION

Operating voltage: 230V Frequency range: 30-70Hz Power consumption: <2W Temperature range: -10 to 40°C at max, 60% RH Pollution degree: 2 Power supply: from mains Open Earth if Earth resistance >50k $\Omega$  nom at 230VAC nom Open Neutral if Neutral resistance >50k $\Omega$  nom at 230VAC nom Complies with BS EN61010-1, CATII 300V